

Hinge Sets General hardware



The Legge hinge set is a selection of components used to hang a door on a pivot, allowing the door to swing both inwards and outwards.

Supplied with a retractable door stop, the door in its usual function operates like any other door. During an emergency, such as when an elderly person, disabled, or ill patient collapses on the other side of the door, it can be swung outwards for easy access.

A simple selection of parts that could ultimately be life saving in certain circumstances. A must for retirement villages, hospitals, nursing homes, and accessible toilets.

Features

- Base models allow doors to be pivoted to swing inwards and outwards
- When the spring loaded door stop is depressed and the privacy bolt is released, the door can then be swung outwards to provide unrestricted access
- Model 13302 accommodates doors to 40kg maximum
- Model 13303 accommodates doors to 80kg maximum
- Pivot system requires non-rebated door frame
- Doors can be centrally pivoted or pivoted to the inside of the door frame
- Where self closing doors are required, the LCN 4021T-ST1895 Series door closer should be specified
- Pivot sets and retractable door stop are manufactured of US304 Grade stainless steel



Warranties	
Mechanical	10 years

Specification guide

Model	Finish
Pivot hinge set	Satin stainless steel SSS
I. Function Select the desired function e.g., Pivot hinge set	DAX13303
2. Finish	

Finish




SSS Satin Stainless Steel

Specifications

Door type	Timber
Material	Stainless steel

13303 Pivot hinge set

Top & bottom angle pivot 30mm x 50mm x 5mm Middle angle plates 20mm x 124mm x 5mm Top plate 20mm x 90mm x 5mm **Finish:** Satin stainless steel




13312 Retractable door stop

54mm x 70mm **Finish:** Satin stainless steel




13302 Special access hinge set


Angle pivot 32mm x 65mm x 6mm Plates 117mm x 28mm x 2mm **Finish:** Satin stainless steel




ALLEGION













13301 Escape hinge set

Closed






Door access blocked



Door access unblocked

Open




Fitting

- 1 With the escape sleeve in position on hinge, fix the hinge to the door and door jamb in the usual manner. Allow a minimum of 3mm spacing between the door edge and door jamb.
- 2 Fix the emergency handle to the door in position shown in the diagram


3 Fix the privacy set in then standard position

Note: Provide door frame stop to the privacy set jamb only. Privacy bolt is ordered separately. After fixing components, test the operation of the door in both normal and emergency operations.






13303 Pivot hinge set



13302 Special access hinge set





13302 Special access hinge set

Normal mode



Retractable door stop





Open

Top (and bottom) door pivot




Closed






Door access blocked



Door access unblocked



© Allegion 2021. All rights reserved. Material and design specifications subject to change without notice. Product colour reproduction is as near to actual product colour as production methods allow. Warning: Products in this brochure are the subject of registered designs and patents. This brochure relates to Australian and New Zealand products only and some product, design or specifications may differ in other countries.

